

Disconnecting the USB cable

After completing the file transmission, you must disconnect the cable in the following way:

- 1 Double-click on the green arrow in the taskbar on the bottom right of the window.
- 2 When the [Stop a Hardware device] message appears, press the [OK] button and disconnect the USB cable.




k

Note :

- The green arrow is not displayed on the Task Bar in Windows 98.
If a "READY" message is shown in Display window, disconnect the USB cable.

YP-ST5 Quick Guide

Location of Controls



Turning Power On and Off

- Power On : Press the ►|| button to turn on the power.
- Power Off : Press and hold the ►|| button to turn off the power.

Playing Music

- Press the ►|| button.
- Playback starts.

Pausing Music


Press the ►|| button to pause playback.

- If no buttons are pressed within 10 seconds(changes depending on settings), the yepp automatically powers off.
- While in Pause mode, briefly press ►|| again to resume playback.

Connecting the USB cable


- Before connecting the yepp to PC, make sure to install USB driver.
Insert the Installation CD into the CD-ROM drive and then click [Install yepp USB Driver].
Complete the installation by the instructions in the order as they appear in the windows.

- 1 Connect a USB cable to the USB port on the computer.
- 2 Connect the other end of a USB cable to the USB cable connection port on the bottom of the player.
 - If you disconnect the USB cable from your PC while implementing a command or initializing during USB driver installation, your PC may not function correctly.
- 3 The USB driver is installed with a message saying that it is searching for a new device. You may not see the display screen during installation. Go to the device manager to check that installation has been successfully completed.
- 4 Upon installation of the USB driver "Samsung yepp YP-ST5 USB Device" will appear in the [System Properties] → [Device Manager].



Downloading/Uploading files

- 1 Connect the player to your PC.
- 2 Open Windows Explorer on PC.
 - Removable Disc is displayed in Windows Explorer.
- 3 Select the file to save and drag-and-drop it into the removable disk icon.
(In numerical, alphabetical order)



Notice :

- The "WRITING/READING" message will appear during file download or upload. Disconnecting the USB cable while "WRITING/READING" is displayed may cause malfunction of the unit.
- Files will not necessarily play back in the order displayed in the Removable Disc in Windows Explorer.